




How to clean Crayola Crayon Maker

General cleaning recommendations to make the Crayola Crayon Maker function properly.

Written By: Melissa



INTRODUCTION



Keeping your Crayon Maker clean is essential to the life and functionality of the device.

Step 1 — Cleaning the Crayon Mold



- Remove crayon mold.
 - Using soap and water, wash mold thoroughly.
- ☒ If wax is is thick and heavily built up, you may need to find a tool to help scrape wax off.

Step 2 — Clean Melting Tray



- To clean wax residue, follow similar guidelines as in Step 1.
- ⓘ Hot water, soap, and scraping the tray work wonders for the upkeep of this device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 02:14:44 PM.